

SAFETY PRECAUTIONS

This machine is intended for commercial use only. It is designed to be operated only by trained and qualified operators only. It is to only be operated in manor to which it is indented, to vacuum dry only debris, dirt, dust or other dry particulate, in an indoor dry environment. Use only recommended tools or accessories by Centaur Floor Machines for this machine.

All Operators must read, understand and practice the following safety precautions.



WARNING: Fire or Explosion Hazard

Never use flammable liquids or operate machine in or near flammable liquids, vapors or combustibile dusts. This machine is not equipped with an explosion proof monitor. The electric motor will spark upon start up and during operation which could cause a flash fire or explosion if machine is used in an area where flammable vapors/liquids or combustibile dusts are present. Do not use to vacuum combustibile or explosive materials, such as coal, grain, hazardous, toxic, or carcinogenic materials.



WARNING: Electrical Hazard. Do not operate with damaged power cord. Do not modify plug. Unplug power before servicing machine. If the supply cord is damaged or broken, it must be replaced by the manufacturer or its service agent or a qualified technician to avoid a hazard.



WARNING: Electrical Shock Hazard. Do not use outdoors. Do not expose to rain. Store indoors. Do not operate with WET Hands.

The following information signals potentially dangerous conditions to the operator of the equipment:

FOR SAFETY:

Do not operate the machine:

- With flammable liquids or near flammable vapors as an explosion or flash fire may occur.
- Unless trained on the use of this equipment and authorized
- Unless operator manual is read and understood
- Unless cord is properly grounded
- With damaged cord or plug
- If not is proper operating condition
- In outdoor areas
- In standing water
- With the use of an extension cord

FILTRATION:

- The SL-6 and SL-8 Vacuums are equipped with cloth filtration and is non-certified for toxic substances such as asbestos, allergens, carcinogens or harmful materials.
- If further clarification of the use of the vacuum is required, please contact Centaur Floor Machines 905-475-5640.
- Cloth filtration is machine or hand washable.

WHEN USING THIS MACHINE:

- Keep suction intake or hose end away from living beings, do not make contact with skin, hair or organs.
- Do not pull machine by plug or cord
- Do not run machine over cord
- Do not pull cord around sharp edges or corners
- Do not close doors on cord
- Do not unplug by pulling on cord
- Do not stretch cord
- Do not handle plug with wet hands
- Do not touch any power connection or surface with wet hands
- Keep cord away from heated surfaces
- Never leave vacuum unattended while plugged in
- Do not pick-up anything burning, or hot materials
- Do not use without proper filters in place
- Use extra care when working on stairs or elevated surfaces
- Always unplug machine when not in use
- Never operate machine with damage or ill sounding
- Never allow children to play on or around
- Never use "aftermarket" parts or cables
- Always use eye protection when operating vacuum cleaner

BEFORE LEAVING OR SERVICING MACHINE:

- Turn off machine
- Unplug cord from wall outlet

SERVICING THIS MACHINE:


- Any components which are enclosed should only be serviced by trained and qualified technicians
- Only use manufacturer supplied replacement parts
- All repairs must be performed by a qualified service person
- Do not modify the machine from its original design
- Contact Centaur Floor Machines to request service centers

WHEN TRANSPORTING THIS MACHINE:

- Get assistance when lifting machine
- Unplug cord from wall outlet
- Use tie-down straps to secure machine to truck or trailer
- Ensure machine is kept +5c Temperature or higher at all times

GROUNDING INSTRUCTIONS:

This machine must be grounded. If it should malfunction or breakdown, grounding provides a path of least resistance for electrical current to reduce the risk of electrical shock. The plug must be plugged into an appropriate outlet that is properly installed in accordance with all local codes and ordinances. Do not remove ground pin. If missing, replace plug before use.



This machine is for use on a nominal 120-Volt circuit and has a grounding attachment plug that looks like the plug illustrated. Make sure that the machine is connected to an outlet having the same configuration as the plug. No adaptor should be used with this machine.