



# How to replace KNOB on floor machine BASE



Remove HITCHPIN but leave spring on the brass stem.



The replacement Knob  
complete with  
Hitchpin  
Spring and  
Washer.  
part # **2E80110**



Push brass STEM (while the spring is on it) in to the hole



As you push, the spring become compressed. Now push hitch pin in to the small hole. The job is done.  
(The spring is not visible on this picture.)